

## Question 9.31

**Topic:** Zero-level gases for O<sub>2</sub> Analyzers

**Question:** Question 9.1 describes "zero air material," which may be used in lieu of a zero-level EPA Protocol gas for daily calibrations of SO<sub>2</sub>, NO<sub>x</sub> and CO<sub>2</sub> monitors. However, "zero air material" is not appropriate for the zero-level calibration of an O<sub>2</sub> analyzer. What types of zero material(s) may be used to calibrate an O<sub>2</sub> analyzer?

**Answer:** The following calibration materials may be used to zero an O<sub>2</sub> analyzer:

- (1) A "zero-level" EPA Protocol gas, consisting of O<sub>2</sub> (at a concentration > 0.0% but ≤ 20.0% of the span value) in nitrogen; or
- (2) High-purity nitrogen, certified by the vendor to contain:
  - \_ Concentrations of SO<sub>2</sub>, NO<sub>x</sub>, or total hydrocarbons \_ 0.1 parts per million (ppm);
  - \_ A CO concentration ≤ 1 ppm;
  - \_ A CO<sub>2</sub> concentration ≤ 400 ppm; and
  - \_ An O<sub>2</sub> concentration < 500 ppm (0.05% O<sub>2</sub>); or
- (3) An EPA protocol gas cylinder containing NO<sub>x</sub> in oxygen-free nitrogen. Note that the "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards" requires that nitrogen oxide standards be blended only with oxygen-free nitrogen containing < 0.5 ppm of oxygen; or
- (4) Any other EPA Protocol gas mixture for which O<sub>2</sub> is either not listed as a component of the mixture on the vendor's certificate of analysis or, if listed, has a concentration < 500 ppm (0.05% O<sub>2</sub>); and nitrogen, with a certified purity of 99.95% or better is used as the balance gas.

**References:** § 72.2; Question 9.1; "EPA Traceability Protocol for Assay and Certification of Gaseous Calibration Standards" (EPA-600/R-97/121; Research Triangle Park, NC; September, 1997)

**History:** First published in the October 2003 Revised Manual; revised in 2013 Manual